

Shower Commode Guide

Fitting Guide for Shower Commodes

Shower commodes support safe and comfortable toileting and showering. To ensure the correct fit, check key measurements such as seat depth, overall width, and unit depth, especially when positioning over a toilet or in compact spaces.

Allow sufficient clearance for fixtures like cisterns, walls, and grab rails, and ensure there is adequate room for safe transfers.

Always place the commode on a stable, level surface and confirm all components are secure before use. Regular checks help maintain safety and stability.



Code	Description	Internal Width (A)	Internal Height (B)	Internal Depth* (C)	Pan Carrier Width (D)	Pan Carrier Height (E)
Self Propelled Shower Commode						
BTC066200	Weight Bearing Platform - 460mm	415	500	445	370	445
BTC066055	Weight Bearing Platform - 530mm	495	500	500	370	445
BTC066100	Swing Away Footrests - 460mm	415	500	450	370	445
BTC066065	Swing Away Footrests - 530mm	485	500	485	370	445
BTC061305	Swing Away Footrests - 600mm	555	500	485	370	445
Attendant Propelled Shower Commode						
BTC066000	Weight Bearing Platform - 460mm	415	500	445	370	445
BTC066050	Weight Bearing Platform - 530mm	495	500	500	370	445
BTC061400	Weight Bearing Platform - 600mm	550	500	420	380	445
BTC065900	Swing Away Footrests - 460mm	415	500	450	370	445
BTC066060	Swing Away Footrests - 530mm	485	500	485	370	445
BTC061300	Swing Away Footrests - 600mm	555	500	485	370	445
Tilt and Recline Shower Commode						
BTC066030	Attendant Propelled - 460mm	500	510	610	370	450
BTC066040	Attendant Propelled - 530mm	530	510	610	375	450
Aluminium Shower Commode						
BTC068010	Attendant Propelled - 440mm	370	465	470	250	430
BTC068020	Self Propelled - 440mm	325	465	470	250	430
Bariatric Shower Commode						
BTC061200	Attendant Propelled - 790mm	720	450	650	470	355

*Internal depth indicates clearance needed to push commode securely on top of toilet.