

Alerta Wireless Transmitter



- The Alerta Wireless Transmitter is for use with the Alerta Wireless Fall Prevention products and pairs wirelessly with the Alerta Wall Point Receiver.
- Alerta Wireless Transmitter is for use with Alerta's Wireless; Chair Alertamat, Bed Alertamat, Deluxe Carpet Alertamat, Floor+ Alertamat, WetSense Bed & Chair Alertamats and Alertamat.
- It uses radio frequency technology to connect Alerta Wall Point Receiver with a wireless range of up to 95 meters. Once paired with Alerta Wall Point Receiver it will only transmit to that Wall Point Receiver and will not interfere with other Alerta Wall Point Receivers in use nearby.
- Alerta Wireless Transmitter had the functionality to delay the alarm sounding for Bed & Chair Alertamats to reduce false alarms when the user is repositioning. This means after activation, depending on your choice of delay setting, the alarm will not sound for 0, 2 or 4 seconds on Bed and Chair Alertamats, (does not apply for other devices).

 Contract approved

Support @ Home

Function: Signalling, alarming and localisation

Category: Prescribed

Click [here](#) for more information

Code	Display Name	Total Length	Total Width	Total Height
BEA007672	Alerta Wireless Transmitter	100 mm	10 mm	100 mm