

Spare Parts Breakdown - Aspire Matisse Quattro Lift Recline Chair



1



10




11



9



2



8



3



7



4



5.1



5.2



6



12

CHP227560

Chair Powerlift Recline - Aspire Matisse Quattro - Fog - 4 Motor - 159kg

No.	Item Code	Item Description
1	GSP510580	Actuator - Back - Aspire Lift Recline Chair Matisse - Blue Plug
2	GSP510045	Actuator - Headrest - Aspire Lift Recline Chair Matisse - Yellow Plug
3	GSP510600	Actuator - Lift - Aspire Lift Recline Chair Matisse - Green Plug
4	GSP510055	Actuator - Lumbar - Aspire Lift Recline Chair Matisse - Grey Plug
5.1	GSP400649	Battery ONLY - for Battery Backup - All Aspire Lift Recline Chair Lift / ComfiMotion Care / LUX Beds
5.2	GSP400648	Transformer ONLY - for Battery Backup - All Aspire Lift Recline Chair Lift / ComfiMotion Care / LUX Beds
6	GSP510237	Control Box - Aspire Lift Recline Chair Matisse
7	GSP510630	Frame - Complete Base - Aspire Lift Recline Chair Matisse
8	GSP510640	Frame Assembly - Headrest / Lumbar - Aspire Lift Recline Chair Matisse
9	GSP510650	Handset - Aspire Lift Recline Chair Matisse
10	GSP511560	Mains Power Cable - Aspire Lift Recline Chair Matisse
11	GSP511550	Power Supply Extension Cord - Aspire Lift Recline Chair Matisse
12	GSP510610	Cover - Headrest/Armrest