


Spare Parts Breakdown - Aspire Waterfall Day Chair



CHP208070/CHP208071/CHP208075/CHP208076

Aspire Waterfall Day Chair - Ink/Latte/Oatmeal/Mocha

| | | |
|---|-----------|--|
| 1 | GSP400191 | Seat Cushion - Ink Vinyl |
| 1 | GSP400192 | Seat Cushion - Latte Vinyl |
| 1 | GSP400193 | Seat Cushion - Mocha Fabric |
| 1 | GSP400194 | Seat Cushion - Oatmeal Fabric |
| 2 | GSP400177 | Padded Backrest - Ink Vinyl |
| 2 | GSP400183 | Padded Backrest - Latte Vinyl |
| 2 | GSP400187 | Padded Backrest - Mocha Vinyl |
| 2 | GSP400188 | Padded Backrest - Oatmeal Vinyl |
| 2 | GSP400175 | Seat/Backrest Frame with Covers - Ink Vinyl |
| 2 | GSP400180 | Seat/Backrest Frame with Covers - Latte Vinyl |
| 2 | GSP400190 | Seat/Backrest Frame with Covers - Oatmeal Fabric |
| 2 | GSP400185 | Seat/Backrest Frame with Covers - Mocha Fabric |
| 3 | GSP400115 | Padded Armrest & Hardware - Ink Vinyl |
| 3 | GSP400120 | Padded Armrest & Hardware - Latte Vinyl |
| 3 | GSP400130 | Padded Armrest & Hardware - Oatmeal Fabric |
| 3 | GSP400125 | Padded Armrest & Hardware - Mocha Fabric |
| 4 | GSP400050 | Rubber End Cap for Leg |
| 5 | GSP400015 | Leg Extension Tube |
| 6 | GSP400045 | Push Button and Spring |